GEOTECH
CONSULTANTS, INC.

13256 NE 20th St, Suite 16
Bellevue, WA 98005

425-747-5618
FAX 425-747-8561
www.geotechnw.com

DAILY FIELD REPORT

TRAVEL/PREP TIME	JOB NUMBER
	14247
TIME ON SITE	DATE
1515	1/14/15
TIME OFF SITE	DAY OF WEEK
1600	Wednesday
HOURS CHARGED	WEATHER
2.0	Clear, cool, dry

SITE LOCATION		CLIENT/OWNER	
10143 Northeast 64th Street	Kirkland	Lakeview Drive, LLC	
GENERAL CONTRACTOR	CONTRACTOR SUPERINTENDENT	MILES	PERMIT NUMBER
Lakeview Drive	Karl	8	
GRADING CONTRACTOR	GRADING SUPERINTENDENT	VISITORS	PAGE OF
Bobby Wolford	Bob	-	1 of 1

COMMENTS

Today I met at the site with Karl of Lakeview Drive, and Bob of Bobby Wolford. This is our first visit during the construction process. The old house has been demolished and removed, and the remainder of the property has been stripped to beneath the sod. The resulting soil is essentially wet, soft topsoil.

Test pits were excavated near the southwest and southeast, lower, corners of the building. These found hard silt at a depth of 2 to 3 feet below the existing grade. This hard silt is light gray in color. In the north end of the building, a test hole found hard silt at a depth of approximately 3 feet.

The hard silt is suitable for bearing. Due to the moisture sensitivity of this soil, as the foundations are being scraped clean with a grade bar, the silt should be protected with a minimum 6-inch thickness of clean crushed rock (quarry spalls or railroad ballast rock) or clean crushed concrete. This will protect the subgrade from disturbance while the forms and rebar are being placed.

Within the footprint of the structure, it will be necessary to scrape off the soft, dark brown silt to the firmer, light brown silt beneath in the slab areas. This silt should also be protected with a layer of clean rock for proper slab support.

The on-site soils are not suitable for reuse as compacted fill, due to their high silt and moisture contents. Imported fill will be required.

Along the northeastern corner of the building, the new foundation walls will be backfilled up to the adjacent sidewalk grade. The existing rockeries that retain the fill beneath the sidewalks can be left in place, and should then be backfilled against once the building foundation walls are constructed.

NEXT SITE VISIT	
-	
COPY TO	SIGNATURE
nebildlkmen@hotmail.com; luchsingerj@baylisarchitects.com	Marc R. McGinnis (Marc R. McGinnis)